Phone & Feature Guide

AT&T Z998

Phone Setup

You'll need to set up your AT&T Z998 before you can explore all its great features.

① Remove the back cover via the notch at the bottom of the phone.

② Insert the micro-SIM with the cut corner first and the gold-colored contacts facing down.



③ Insert the microSD™ card (sold separately) with the gold-colored contacts facing down.

④ Insert the battery, making sure the connectors align. Gently push down on the battery until it clicks into place.

⑤ Replace the back cover.

Get to Know Your Phone

Note: For more information on your device, visit **att.com/Tutorials**.

Touch Screen and Navigation

Your phone features a capacitive touch screen, so you can gently tap, quickly swipe, or pinch with two fingers to navigate.

Navigating Your Phone

- Use your fingertip to lightly touch the screen.
- Use quick flicks of your finger on the touch screen to swipe up, down, left, and right.
- Spread two fingers apart or pinch them together on the screen to zoom in or out on a web page or a gallery image.
- The Notifications panel at the top of the screen provides quick access to alerts including new messages, email, and voicemail. Swipe down on the black bar to see more details. Flick up or press to close the panel.
- To return to the previous screen, press .
- Press at any time to return to the main home screen. Press and hold to access your recent apps.
- Press to access menu options for the screen you are on.
- Tap to access applications on your phone.

Customize a Home Screen

Change the wallpaper, add shortcuts to apps and widgets to the home screen, and create folders to organize and personalize your phone.

Set the Wallpaper

① Press and hold a blank part of the home screen and touch **Home** or **Lock screen**.
② Tap **Gallery**, **Live Wallpapers** or **Wallpapers** and choose the image or animation you want to use as the wallpaper.
③ Tap **Done** (for Gallery images) or **Set wallpaper**.

Add Shortcuts to the Home Screen

① Tap and then choose **Apps** or **Widgets**.
② Press and hold the icon of the item you wish to add and then drag it to a home screen.
③ To move an icon, press and hold it and drag it to a new location. To delete it, drag it to **Remove**.

Organize Your Home Screens

① Press and hold an icon and drag it to **folder**.
② To add apps, drag additional icons to the folder.
③ To rename a folder, tap it and then tap the name to bring up the keyboard. Enter a name and tap **Done**.

Find More Information

On The Web

- Find tutorials at **att.com/Tutorials**.
- Find device specifications, user manuals, troubleshooting, and user forums at **att.com/DeviceSupport**.
- Manage your wireless account, including suspending service if your phone is stolen, at **att.com/myatt**.

On The Phone

- To access how-to videos for the Z998, tap > **Device Help**.
- Call AT&T Customer Care at **1-800-901-9878** or dial **611** from any AT&T mobile phone for assistance with your service or device.

Accessories

Accessories for your smartphone are available at **att.com/WirelessAccessories** or visit your local AT&T store.

Bluetooth Headset

Headset

USB Cable

Vehicle Power Charger

Calling and Voicemail

Call friends and family and check voicemail in just a few simple steps.

Make a Call

① From the home screen, tap .
② Enter a phone number or spell the name of a contact. Tap the contact and then tap to place the call.

Check Voicemail

① From the home screen, tap .
② Press and hold the **1 Key**.
③ Follow voice prompts to listen to messages.

GoPhone Account

Auto Refill

Take the hassle out of refilling your account by enrolling in Auto Refill.

From Your Device

① Call **611** from your phone.
② From the main menu, say "More options," and then say, "Set up auto pay."

Online

① Visit **att.com/mygophone**.
② Under **Auto Refill**, select **Sign Up** > **Manage My Account** > **Auto Refill**.

Add Money with a Credit Card, Debit Card, or Checking Account

① Call **611** from your phone and say "Add money."
② Go to **www.att.com/mygophone** and select the **Electronic payment** link.

Add Money by Purchasing a GoPhone Refill Card

Add money by purchasing a GoPhone Refill Card, which is available at authorized retail locations nationwide. With most refill cards, you can add the value directly from your phone.

- Dial **611** from your phone and say "Add money."
- Enter ***888***, followed by your PIN number, the **# key**, and then press **Send**.
- Go to **att.com/mygophone** and select the **Use Refill Card** link.

Contacts

Keep the contact information of your favorite people in the address book. Importing and editing contacts is easy.

Import Contacts from SIM card

① From the home screen, tap .
② Press and tap **Import/export** > **Import from SIM card**.
③ Tap the contacts you wish to import, or tap **All** to select all contacts, and then tap **Import**.

Edit a Contact

① From the home screen, tap .
② Tap a contact name and tap **Edit**.
③ Change details as needed and tap **Done**.



© 2013 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks contained herein are the property of their respective owners.

Printed in USA

P/N 079584505637

Email

Access your Gmail™, corporate email, and personal email wherever you are!

Email Setup

1. From the home screen, tap .
2. Enter your email address and password and then tap **Next**.
3. Confirm email account settings and tap **Next**.
4. Name the account, enter your name as it will appear on outgoing messages, and tap **Next**. Your email will begin to synchronize with your phone.

Create and Send an Email

1. From your email inbox, tap .
2. Enter an email address or tap to access your contacts list.
3. Enter a subject and email message. To attach files to the email message, press , tap **Attach file**, and make your selection.
4. Tap **Send** to send your message.



Note: To set up corporate email, contact your IT administrator.

Update Your Apps

Updating apps is quick and easy.

1. From the home screen, tap > .
2. Press and tap **My apps**.
3. Tap . Or, if you'd like to update apps individually, tap the desired app > **Update** > **Accept & download**.
4. Once installed, you will see a notification in the Notifications panel. Tap the notification to open app or locate it in the App tray or on the home screen.

Text and Picture Messaging

Send text or picture messages to communicate privately and quickly.

Send a Text Message

1. From the home screen, tap .
2. Tap to start a new text message.
3. In the **To** field, enter a number or a contact name or tap to access your contacts.
4. Tap the **Type message** field and enter your message.
5. Tap **Send** to send the message.

Send a Picture Message

1. Follow steps 1-4 above.
2. Tap .
3. Tap **Pictures** and select desired picture.
4. Tap **Send** to send the message.

Please don't text and drive.

Camera and Video Recording

Take pictures and record videos right from your phone with the camera and camcorder and then share them with friends and family.

Take a Picture

1. From the home screen, tap .
2. Tap to adjust your camera settings. Zoom in and out by dragging the slider bar.
3. Tap or press a **Volume key** to take a photo.

Record a Video

1. In camera mode, tap to switch to the camcorder.
2. Tap to start and tap to stop recording video.

Share a Picture or Video

1. From the home screen, tap > .
2. Tap an album and then tap a photo or video.
3. Tap **Share** and select an option for sharing.

Bluetooth® and Wi-Fi®

Pair with other *Bluetooth* devices or connect to a Wi-Fi network.

Connect to a Bluetooth *Headset*

1. From the home screen, press and tap **System settings** > **Bluetooth**.
2. Tap to turn *Bluetooth* on.
3. Your phone will automatically search for devices. Tap the name of the device to pair and connect with it.

Connect to Wi-Fi Network

1. From the home screen, press and tap **System settings** > **Wi-Fi**.
2. If Wi-Fi is off, tap to enable it.
3. Tap a network name. Enter a password if required and then tap **Connect**.



Internet

Browse the web and open multiple windows at the same time, as you would on your PC.

Open a Web Page

1. From the home screen, tap .
2. Tap the address bar, enter a web address, and tap **Go**.

Browsing Options

- **Go back:** Tap .
- **Go forward:** Tap .
- **Refresh the page:** Tap .
- **Open another browser window:** Tap .
- **View open browser windows:** Tap .

Multitasking

You can perform multiple tasks at once with the Z998, such as looking at an email while on a phone call.

1. While on a call, press .
   - To begin a new text message or email, tap or .
   - To access additional applications, tap .
2. To return to the call screen, tap .

AT&T Services

Check out these handy apps from AT&T.

- **AT&T Drive Mode™:** Silence notifications, set an auto-reply so people will know you're driving, and more.
- **AT&T Locker™:** Safely store and share all your photos, videos, and documents with up to 5 GB of free storage.
- **AT&T Navigator®:** Get voice-guided, turn-by-turn driving directions and traffic updates.
- **AT&T Smart Wi-Fi:** Maximize your battery performance and data plan, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data usage.
- **Data Balance:** Track your remaining data and messaging balance.
- **Mobile TV:** Watch LIVE, on-demand, and downloadable mobile TV.

Data rates may apply. Mobile TV and AT&T Navigator require a separate subscription. Mobile TV requires mobile broadband service. Service not available in all areas. Programming subject to blackout restrictions. Download and watch capability available for select content, requires Wi-Fi connection, and is available for viewing for limited time periods.

Google Play™ Store

Browse and download apps, games, books, movies, and more with Google Play.

Access Google Play

1. From the home screen, tap > .
2. Sign in with your existing Google™ account or create one following the steps on the screen.

Navigate Google Play

1. Tap a category to browse popular apps, games, movies, and music organized by popularity or category.
2. Tap to search the Play Store for a specific game or app.
3. To install, tap the app and follow instructions. Once installed, you will see a notification in the Notifications panel. Open the app from this notification or by locating the app in the App tray .

Note: A Google Wallet™ payment method is required to purchase apps.

AT&T DriveMode®

AT&T DriveMode allows you to silence notifications and set an auto-reply so people will know you're driving.

1. From the home screen, tap > **AT&T DriveMode**.
2. Read the terms and conditions and tap **I Accept** > **Continue**.
3. Set your AutoReply message and tap **Next**.
4. Select the features you want to set on AutoReply and tap **Next**.
5. Choose if you want to call/receive calls from up to five people while DriveMode is enabled. When you're finished, tap **Next**.
6. Enable or disable Automatic Mode and tap **Finish** > **Continue**.